# CECO Frequency Counter



#### FC1003 Handheld Radio Frequency Counter

- A more practical frequency counter
- Frequency range: 1 MHz 3 GHz
- Weight: 210g
- Case: 80 mm  $^{\star}$  68 mm  $^{\star}$  31 mm stamped aluminum with black anodized finish
- Battery: Internal 4 \* AA 600 mAH NiCd pack
- 10 digit liquid Crystal Display
- Low power consumption (Average 6 hour battery life)
- Hold switch to lock display
- Digital filter to prevent display of random noise
- Low battery indicator
- Ultra sensitive synchronous detector 16 section bargraph to show RF signal strength
- High speed 300 MHz direct counter with 0.1 Hz resolution
- 4 selectable gate speeds

客戶服務熱線: 2729 3271



華輝無綫電行有限公司 WELFARE Electronic Component Ltd.

Tel: (852) 2729 3271 Fox: (852) 2387 6919 G/F & 1/F, Ming Chu Building, 195-201 Apillu Street Shorn Shul Po, Kowloon, Hong Kong 李进士德亚女性自然的15.2012 阿拉迪特丁另一連各區









本公司持有政府認可

# ACECO FC1003 Frequency Counter

#### **Introduction**

The Aceco FC1003 hand-held frequency counter is a more practical counter, even advanced features such as field strength measurement are incorporated. It is compact, truly pocket sized, test instrument designed for ease of use and dependable performance. Supplied as a complete with internal NiCd pack, AC wall charger and 7 section telescopic antenna.

### **Specifications**

Frequency range	1 MHz - 3 GHz	
Weight	210 g	
Size	80 mm high x 68 mm wide x 31 mm deep	
Impedance	50 Ohms (BNC Socket)	
Case	Stamped aluminum with black anodized finish	
Battery	Internal 4 x AA 600 mAH NiCd pack	
Power	9 VDC 300 mA	
Timebase	Less than 1 PPM at room temperature	

#### **Features**

- 10 digit Liquid Crystal Display
- Filter to prevent display of random noise
- Low power consumption (Average 6 hour battery life)
- Supplied with NiCd pack, AC wall charger and telescopic antenna
- Hold switch to lock display
- Low battery indicator
- Ultra sensitive synchronous detector 16 section bargraph to show RF signal strength
- High speed 300 MHz direct counter with 0.1 Hz resolution
- 4 selectable gate speeds

客戶服務熱線: 2729 3271



華輝無綫電行有限公司 WELFARE Electronic Component Ltd.

Tel: (852) 2729 3271 Fax: (852) 2387 6919 G/F & 1/F. Ming Chu Building, 195-201 Apliu Street Sham Shui Po, Kowloon, Hong Kong 香港九龍逐水步鳴麥街199-201號 明政權地下及一權全屬







# ACECO FC1003 Frequency Counter

#### Controls

- Power Switch This slide switch turns the counter on and initiates a 2 second test of all the LCD segments.
- 2. Range Switch This should be switched to the 300 MHz position for frequencies between 1 MHz and 300 MHz and switched to the 3 GHz position for frequencies between 10 MHz and 3 GHz.
- 3. Filter Switch This slide switch turns the filter on and off.
- 4. Hold Button This holds the current display and stops the counter from counting.
- Gate Button This selects the gate or measurement time. A longer gate time allows counting for longer period and results in higher accuracy.
- 6. Calibration The calibration adjustment opening is located on the front panel of the counter. This allows access to the trimmer capacitor that provides about a 10 PPM adjustment range of the time base oscillator. This is not usually necessary but to do so read a signal of an known frequency before adjusting the trimmer for correct frequency display. If you calibrate at 4.1943 MHz or above then the counter will be more accurate.


## **Warranty**

Welfare Electronic Component Ltd. guarantees the counter and accessories for one year against defects in manufacture. This warranty does not cover items that have been modified, subject to unauthorized repairs, misuse or abuse. This warranty does not cover damage caused by excessive power levels applied to the signal input. Never make any kind of connection between the counter and a transmitter.

客戶服務熱線: 2729 3271













# ACECO Frequency Counter

### **Hints And Tips**

#### NiCd Operation

This frequency counter can operate for up to six hours from its fully charged NiCd batteries. They are charged when the unit is plugged into the supplied AC/DC adapter. Full recharge will occur over12 to16 hours. Before recharging the batteries you should be deep cycled occasionally by allowing them to completely discharge to maintain maximum battery capacity. The NiCd batteries should last for several years. However, it is a good idea to check them every twelve months for signs of corrosion or leakage. Always replace the whole set if any one cell fails.

#### 1. Signal Input

When using the counter with an antenna for signal pick up, random frequencies may appear on the display. This is quite normal and is caused by the high gain of the receiver circuits which amplify noise in the absence of a strong readable signal. Never get the unit too close to a transmitter as internal damage will result.

#### 2. Antenna Selection

The supplied telescopic antenna is best for general purpose use. This is because its length can be adjusted to suit the frequency required. Usually you will want a shorter antenna for UHF and a fully extended one for VHF / HF.

#### 3. Reception Distance From Transmitter

The distance from which you will be able to receive frequencies will depend upon the type and location of the transmitting antenna, transmitter output power and the frequency in use.

Some typical distances are:

Cordless Phone	0.3 meters
Cellular Phone	3 - 20 m
CB radio	2 - 8 m
VHF Two Way Radio	3 - 30 m
UHF Two Way Radio	3 - 30 m

客戶服務熱線: 2729 3271





Tel: (852) 2729 3271 Fax: (852) 2387 6919 G/F & 1/F. Ming Chu Bulding, 195-201 Apliu Street Sham Shul Po, Kowloon, Hong Kong 米市 建工作 中國東西的人の政府 開放 建筑 下方,其外原







www.wacl.com.hk

# ACECO Frequency Counter

# **Input Sensitivity (Typical)**

Amplifier	50 Ohm	
Impedance	50 Ohm VSWR less than 2:1	
Range	1 MHz - 3 GHz	
Sensitivity	< 0.8 mV at 100 MHz	
	< 6 mV at 300 MHz	
	< 7 mV at 1.0 GHz	
	< 100 mV at 2.4 GHz	
Max. input	15 dBm	

### RF Signal Strength Bargraph

Frequency	1st Segment	Full Scale
27 MHz	7 mV	100 mV
150 MHz	5 mV	90 mV
800 MHz	10 mV	200 mV

## **Frequency Display Resolution**

Range	Gate Time (Seconds)	LSD	Sample Display
300 MHz	0.0625	10 Hz	300.00000 MHz
	0.25	1 Hz	300.000000 MHz
	1.0	1 Hz	300.000000 MHz
	4.0	0.1 Hz	300.0000000 MHz
3 GHz	0.0625	1000 Hz	3000.000 MHz
	0.25	100 Hz	3000.0000 MHz
	1.0	10 Hz	3000.00000 MHz
	4.0	10 Hz	3000.00000 MHz

客戶服務熱線: 2729 3271



華輝無綫電行有限公司 WELFARE Electronic Component Ltd.

Tel: (852) 2729 3271 Fax: (852) 2387 6919 G/F & 1/F, Ming Chu Building, 195-201 Apilu Street Sham Shui Po, Kowloon, Hong Kong 文明中華漢文中國東州105-2012年 阿拉達曼工具,建全華





