T5 Electrical Testers 1AC II Volt Alert LVD1/LVD2 Volt Light

The fast and easy solution to basic electrical testing

Fluke T5-600 and T5-1000 Voltage, **Continuity and Current Testers**

600.

Fluke T5-600

Fluke 1AC II

1000V ATE

The Fluke T5 testers let you check voltage, continuity and current with one compact tool. Select volts, ohms or current and the instrument does the rest. Model T5-600 measures 600 volts AC/DC, model T5-1000 is designed for 1000 volts. OpenJaw™ current technology lets you check current up to 100 A, without breaking the circuit. The optional H5 holster keeps the test probes and leads ready to test and lets you clip the T5 onto your belt.

Features and Specifications

	T5-600	T5-1000
Display Count	1000	1000
Automatic Selection	•	•
Continuity and Bleeper	•	•
Sleep Mode	•	•
AC Voltage	600V	1000V
DC Voltage	600V	1000V
AC Current	100A	100A
Resistance	1000Ω	1000Ω
Safety range	600V CAT III	1000V CAT III

Battery life: 400 hours Size (HxWxD): 203 mm x 51 mm x 30.5 mm

Weight: 0.38 kg Two year warranty

Fluke 1AC II VoltAlert™

The Fluke VoltAlert AC voltage detector is very easy to use - just touch the tip to a terminal strip, outlet or cord. When the tip glows red and the unit beeps, you know there is voltage on the line.

- It continually tests its battery and its circuit integrity with a periodic double flash visual indication.
- Highest safety rating: CAT IV 1000V
- · Detects voltage without metallic contact

LVD1 Volt Light

Dual sensitivity voltage detector

- Detects voltage from 40V to 300V AC
- Blue light means you're close
- Red light means you're at the source
- · Comes with a versatile clip to secure light to pocket, hat or even panel door

T5-H5-1AC Kit

• T5-1000 H5 Holster
1AC VoltAlert for free

Electrical Tester

Fluke 1AC II VoltAlert™ 5-pack • Buy 4 get 1 FREE

Operating range: 200 - 1000V AC

Batteries: Two AAA Alkaline Size (H): 148 mm



LVD2 Volt Light

Combines bright light and voltage detection in one pen style design

- Dual sensitivity
- Detects voltage from 90V to 600V AC
 - Blue light means you're close
 - Red light means you're at the source
 - Rated to CAT IV 600V

Recommended Accessories T5







11077-eng Rev. 02

TP4 4 mm detachable probes (detachable GS38 probes for the UK) and instruction sheet

Included Accessories

GP

Ordering Information

Fluke T5-600		
Fluke T5-1000		
Fluke 1AC II		
Fluke 1AC II 5PK		
LVD 1		
LVD2		
T5-H5-1AC Kit		

LVD2

T5-600 and T5-1000:

Fluke T5-1000

Electrical Tester **Electrical Tester**

VoltAlert VoltAlert (5-pack) Volt Light Volt Light

AC Volta DC Volta AC Curre Resistanc Safety ra

Two Year Warranty



ACC-T5-Kit