

2. By squeezing the handles together, the punch will move down into the channel, cutting out a slug of metal.

3. A scribe line can be followed by looking down on work in this position. A slot is cut by making successive cuts.

4. To make a sharp 90 degrees turn, pull the tool out of the slot. Turn the work 90 degrees and insert the tool again.

5. By turning the tool before each cut, a 5/16" (7.9mm) minimum radius can be cut.

6. Almost any size or shape hole can be cut by starting with a 3/8" (9.5mm) hole.